
Panasonic

Digital Cordless Phone Model No. **KX-TG1807NZ**

This model includes a base unit with a handset (Model No. KX-TG1805NZ) and an additional handset and charger.

The instructions for all units supplied here are contained in the operating instructions for KX-TG1805NZ.

Please read the operating instructions before using these units.



Note:

- The handsets have been pre-registered for use with the base unit.
- If you want to know the handset number, press **(INT)** on the handset when in standby mode. The number will be shown on the display of the handset.

